



# LCD CONSOLE



DC-71101/DC-72101

# USER MANUAL

## DC-71101

### Package Inside

LCD Console	x 1
USER Manual	x 1
Power Cord	x 1
Rack-Mount Brackets	x 2
Screws (for Brackets)	x 12
Key	x 2

### Features

- The keyboard, mouse and the 15 inch LCD are built into the LCD display.
- Support of the resolution of 1024x768 pixels at, 75 Hz.
- Enables the installation of a hanging frame in a 19 inch casing system with a space requirement of 1 HE.
- No additional software necessary.

### Specifications

Function		DC-71101
LEDs	Power	1
Console Port	Keyboard	1x6 pin mini-DIN Female (PS/2)
	Mouse	1x6 pin mini-DIN Female (PS/2)
	Monitor	1x HD-15 Female (Std. VGA/SVGA)
	Audio	1x 3.5 Stereo Plug
VGA Resolution		1024x768 pixel at 75Hz
Power		AC 100~240V, 50~60Hz
Housing		Metal
Weight		12.1Kg
Dimensions (LxWxH)		600x447x48 mm

### Keyboard and Mouse Specifications

Keyboard	Standard 104 keys
Mouse	Touch pad module

### LCD Monitor Specifications

Size	15 inch
Screen Type	TFT
Contrast	500:1
Brightness	250 cd/m <sup>2</sup>
View Angle	130°
Resolution	1024x768 pixel at 75Hz
Response Time	12 ms
Display Color	16.2 M

# LCD Monitor Operation

## Keypad Define

Power key: Use this key to turn on or off the LCD monitor.

Menu key: Use this key to open the OSD menu or to return to a previous menu or to exit the OSD menu.

Up key: Use this key to highlight an item in the menu, to move a highlighted function up, or to increase the numeric value (parameter) in a certain menu.

Down key: Use this key to highlight an item in the menu, move a highlighted function down, or decrease the numeric value (parameter) in a certain menu.

Auto key: Use this key to automatically adjust the image position and phase, and return to the previous menu or to exit a highlight item.

If the screen is not in a full screen graphic mode (such as in a DOS) or is connected with an allocator, the position of the appeared image may be adjusted automatically and then deviated. By then, it is necessary to enter into the OSD menu to manually adjust the level or vertical position and phase.

## OSD Control Function List

1. Color:

- Contrast
- Brightness
- Color Adjust
- Color Temp.: 9300, 6500, 5800, 5RGB, USER
- Exit

2. Image Setting:

- Clock
- Phase
- Gamma
- Sharpness
- Exit

3. Position:

- H.Position
- V.Position
- Exit

4. OSD Menu:

- OSD H.Pos
- OSD V.Pos
- OSD Timer
- Exit

5. Language:

English, Français, Deutsch, Español, 繁體中文, 简体中文, 日本語

6. Misc.:

- Signal Source
- Reset
- Factory Mode
- Exit

7. Exit

Note: Press Up key or Down key is to adjust the volume, when it is without OSD menu.

# DC-72101

## Package Inside

LCD Console	x 1
USER Manual	x 1
Power Cord	x 1
Rack-Mount Brackets	x 2
Screws (for Brackets)	x 12
Key	x 2

## Features

- The keyboard, mouse and the 17 inch LCD are built into the LCD display.
- Supported by 1280x1024 pixels at 75 Hz.
- Enables the installation of a hanging frame in a 19 inch casing system with a space requirement of 1 HE.
- No additional software necessary.

## Specifications

Function		DC-72101
LEDs	Power	1
Console Port	Keyboard	1x6 pin mini-DIN Female (PS/2)
	Mouse	1x6 pin mini-DIN Female (PS/2)
	Monitor	1x HD-15 Female (Std. VGA/SVGA)
	Audio	1x 3.5 Stereo Plug
VGA Resolution		1280x1024 pixel at 75Hz
Power		AC 100~240V, 50~60Hz
Housing		Metal
Weight		13.2Kg
Dimensions (LxWxH)		600x450x48 mm

## Keyboard and Mouse Specifications

Keyboard	Standard 104 keys
Mouse	Touch pad module

## LCD Monitor Specifications

Size	17 inch
Screen Type	TFT
Contrast	500:1
Brightness	300 cd/m <sup>2</sup>
View Angle	140°
Resolution	1280x1024 pixel at 75Hz
Response Time	8 ms
Display Color	16.2 M

# LCD Monitor Operation

## Keypad Define

Power key: Use this key to turn on or off the LCD monitor.

Menu key: Use this key to open the OSD menu and enter to next menu or to highlight a confirmed function.

Up key: Use this key to highlight an item in the menu, to move a highlighted function up, or to increase the numeric value (parameter) in a certain menu.

Down key: Use this key to highlight an item in the menu, to move a highlighted function down, or to decrease the numeric value (parameter) in a certain menu.

Auto key: Use this key to automatically adjust the image position and phase, and return to the previous menu or to exit a highlight item.

If the screen is not in a full screen graphic mode (such as in a DOS) or is connected with an allocator, the position of the appeared image may be adjusted automatically and then deviated.

By then, it is necessary to enter into the OSD menu to manually adjust the level or vertical position and phase.

## OSD Control Function List

1. Color:

- Contrast
- Brightness
- Color Adjust
- Color Temp.: 9300, 6500, 5800, 5RGB, USER
- Exit

2. Image Setting:

- Clock
- Phase
- Gamma
- Sharpness
- Exit

3. Position:

- H.Position
- V.Position
- Exit

4. OSD Menu:

- OSD H.Pos
- OSD V.Pos
- OSD Timer
- Exit

5. Language:

English, Français, Deutsch, Español, 繁體中文, 简体中文, 日本語

6. Misc.:

- Signal Source
- Reset
- Factory Mode
- Exit

7. Exit

Note: Press Up key or Down key is to adjust volume, when it is without OSD menu.

### Trademarks:

All the companies, brand names, and product names referred to this manual are the trademarks or registered trademarks belonging to their respective companies.