



Travel Charger, USB Type-C™, 45W



User Manual 31812

The ednet Travel Charger USB Type-C™ allows you to charge all of your devices (Notebooks, Tablets, Smartphones, Power Banks, Speakers, etc.). It can be used in more than 100 countries, thanks to the three included plugs (EU/US/UK). And its features Power Delivery 2.0.

The USB-C charging port can be used to charge notebooks (45W max.). The two USB-A ports can be used to recharge your other mobile devices quickly and efficiently (tablets, smartphones, cameras, speakers, power banks, etc.). It is the perfect companion for the home or office or on the road.

Product Features:

1. Fast charging with up to 45W of power.
2. Perfect solution for:
Apple Macbook, Dell, HP, Google Chromebook, Lenovo, Acer, Asus and other devices using USB-C Power Delivery 2.0.
3. Convenient for travel use with interchangeable AC plugs for different countries.
4. Power USB-C and USB Type-A devices simultaneously.
5. Worldwide use with AC input 100-240V.
6. Multiple safety protection: over current protection, over voltage protection, short circuit protection, over temperature protection.

(*All brand names and trademarks are properties of their respective owners.)


Product specifications:

Input:	AC 100-240V, 50/60Hz 1.2A
USB-C Output:	DC 5-20V/3A (max)
USB-A Output:	DC 5V/3A (max.)
Power:	45W (max.)
Size:	69*67*32mm
Weight:	135 g


Package Content:

- 1x USB-C Charging Adapter
- 3x Power Plugs (EU, UK, US)
- 1x USB-C cable
- 1x User guide

Product Diagram:



Operation Instruction:



1. Connect the travel charger to the wall socket directly.
2. When you want to charge for your USB-C devices, connect the USB-C cable into the USB-C output port of charger and insert the other end of the USB-C cable into the power port of your laptop computer, then it works.
3. Plug your device to the USB-A ports when you want to charge iPad/tablet PCs and mobile phones.

Caution: This adapter supports power 45W max. If your used power exceeds 45W, the adapter will occur to be over-load protection. When you re-plug the connection, then it will recover to normal work.



Notes:

Please read this manual and its instructions carefully before use. We are not responsible for any damage caused by incorrect or reckless operation.

Important Safety Information:

This safety guideline is to help you operate your power adapter safely, to ensure your personal safety and reduce the risk of fire, electric shock or injury.

1. Do not connect a binded cord to the charger.
2. Do not place the device near heating elements.
3. Do not bend the pins of the plug.
4. If there is any strange sound, smoke or odor, unplug the charger immediately.
5. Do not disassemble (It may cause fire or electric shock)
6. Ensure to plug the product firmly.
7. Ensure not to use a damaged cable. (It may cause fire or electric shock)
8. Do not place the product on a bed, bag or inside a closet that is not good for ventilation.
9. Always wipe off the product with soft fabric, not water mop.
(water may cause electric shock)
10. Keep clean the power plug (Dirt/dust may cause a short circuit and fire)
11. Keep the product out of reach of children.
12. Unplug the charger if you don't use the product for a long time.
(It may cause heat, fire and electric shock)

Herby Assmann Electronic GmbH, declares that the Declaration of Conformity is part of the shipping content.

If the Declaration of Conformity is missing, you can request it by post under the below mentioned manufacturer address.

www.assmann.com

Assmann Electronic GmbH

Auf dem Schüffel 3

58513 Lüdenscheid

Germany

