



Type C Power Bank 10000mAh




Manual 31898

User Manual

For optimum performance and safety, please read these instructions carefully before operating the product. Please keep this manual for future reference.

Product introduction



Features

1. Metallic design, compact and stylish.
2. Type-C port for quick charge and discharge.
3. Multiple protection systems against overcurrent, overvoltage, overload and short circuit.
4. Smart LED display for remaining power.

Specifications

Cell type:	Li-ion cell
Capacity:	10000mAh/37.4Wh
Input:	USB Type C 5V/2.4A (max) Micro USB 5V/2.1A (max)
Output:	USB Type C 5V/2.4A (max) USB A 5V/2.1A (max)
Dimensions:	102*77*21.9mm
Weight:	270g±10g

How to use the power bank

1. Turn on the power bank: Short press the power button, the LED power indicator lights up and the power bank starts up.
2. Turn off the power bank: The power bank will turn off automatically after 20 seconds if it is not charging.

Note: The mobile power bank will automatically power on when connected.

How to charge the mobile power bank

1. Charge via computer or adapter with USB port.
2. The LED indicators will flash during the charge cycle.
3. All LED indicators will light up when the power bank is fully charged.

Note: Charge and restart the mobile power bank while it is locked or in shortcut protection state due to incorrect operation.

How to test the remaining power

Press the power button to check the remaining power status:

LED Light (● ON ○ OFF)	Capacity
⊙ ○ ○ ○ ○	0-5%
● ○ ○ ○ ○	5%-25%
● ● ○ ○ ○	25%-50%
● ● ● ○ ○	50%-75%
● ● ● ● ○	75%-100%

- ⊙ LED indicator flashes
- LED indicator off
- LED indicator on

How to charge your device

Fits new MacBook, LeTV Mobil, Nokia N1 and the upcoming major models with USB3.1 port

1. Use your original USB data cable or our standard cable to connect.
2. Connect the device to the mobile power bank.
3. Turn the mobile power bank on.
4. Disconnect your device after it is fully charged.

Caution

1. Fully charge the mobile power bank at first use.
2. Use a standard cable with respective specifications; otherwise your mobile power bank may be damaged.
3. Verify that the voltage of the device is 5V before charging.
4. Do not drop, knock, disassemble or attempt to repair the mobile power bank yourself.
5. Do not immerse the mobile power bank in water or other liquids.
6. Do not expose the mobile power bank to heat sources or flammable substances.
7. Do not leave the mobile power bank in your car, strong light and high temperatures will lead to product damage.
8. Keep the mobile power bank away from children.
9. Do not insert any item into the mobile power bank's USB ports to avoid damages.
10. Fully charge your mobile power bank every four month to avoid a shortened life cycle.

Hereby ASSMANN Electronic GmbH declares that this device is in compliance with the requirements of Directive 2014/30/EU and Directive 2011/65/EU for RoHS compliance. The complete declaration of conformity can be requested from the manufacturer.

Warning:

This device is a class B product. This equipment may cause some radio interference in living environment. In this case, the user is requested to take respective measures to prevent interference.

www.assmann.com
Assmann Electronic GmbH
Auf dem Schüffel 3
58513 Lüdenscheid
Germany

