

**ednet.**

**Spectro LED  
Bluetooth<sup>®</sup> Speaker**



**Manual**

33042

## **Important Safety Instructions**

- ◆ This speaker is designed to protect against splashing water sprayed at all angles. Dropping the whole unit in body of water may damage the product.
- ◆ Keep speaker away from any source of heat.
- ◆ Adjust the volume to a suitable level so as to avoid damaging your hearing, or the unit itself.
- ◆ If does not use this speaker for long time, please charge at lease once within one month, in order to prevent the lithium battery from causing and damaging because of excessive consumption.

## **Features**

### **1. Five Multi-colored LED Themes**

Full spectrum light themes matching with your music

### **2. Bluetooth Music play, BT 4.0 version**

Bluetooth 4.0 stereo music playing

### **3. NFC (Near Field communication)**

One touch easy pairing with your NFC Smartphone

### **4. Mobile Hands-free Function**

Support mobile hands-free communication

### **5. AUX IN**

Work as the external speaker by connecting to the audio source of computer, mobile, PSP/MP3/MP4 etc.

### **6. USB Sound card**

USB Sound Card, charging functions can be achieved via the same USB cable

## **Technical Data**


|           |       |        |                      |
|-----------|-------|--------|----------------------|
| Voltage   | DC 5V | Aux In | 3.5mm                |
| Output    | 4W    | N.W    | 235g                 |
| Impedance | 4Ω    | Size   | 90.0 × 90.0 × 46.5mm |










## **Package Contents**

- Speaker
- USB cable, 3.5mm audio cable
- Manual
- Strap

## SLOT AND KEYS


### A. KEYS




1.  Short press: Pause/Play/Mute/Hang off/Answer the Call  
Double click: Dial back the last call
2.   Short Press: previous/Next song  
Long Press: Volume decrease/increase
3.  Short Press to Switch the LED Themes
4.  Short Press to change different mode
5.  +  Reduce the lightness
6.  +  increase the lightness

### B. SLOT

#### Slot




1. **AUX in slot:** Insert 3.5mm audio cable, press  "Aux in mode", work as the external speaker of audio source of computer, PSP/MP4 Etc.  
Power/Working status indicator:
  - i. Blue color – normal working
  - ii. Charging – orange
  - iii. Lower Power – Flash (orange)
2. **Micro USB Slot:** Connect with computer enter into USB sound mode, card reader (Power off status), and charging the speaker
3. **ON/ OFF:** Power on/off

## Instructions

### **Power on/off:**


Switch the button to power on/off the speaker Bluetooth

**Bluetooth Pairing:** Press  to enter the Bluetooth mode, now please turn on the Bluetooth function of your mobile/ other devices. And start to search for Bluetooth devices, the "33042" will be found, please connect it. (The speaker will voice "Device paired" when connecting).

### **NFC function:**

(It requires the mobile has the NFC function and the speaker need under Bluetooth mode)

Turn on the mobile's NFC function and make the mobile touch the speaker's NFC area. The mobile will remind you to pair with the Bluetooth device. Choose yes to complete the pairing.



### **Bluetooth/ NFC Music Play:**


Please turn on the mobile or other devices' music player, and speaker will play the selected music.

## Mobile Hands-free communication:

- ① Answer the call

Short Press  Answer the call.

- ② Hang off


Press  again to hang off the call

- ③ Dial Back the call


Double press the  button, Dial the last call back

## LED Themes


Short press  to switch the LED Themes, there are five different LED themes




Groove




Neon



Rainbow




Club



Equalize

## AUX in

Use the 3.5mm audio cable included to connect the speaker to an audio source

(PC, MP3/MP4, mobile phone). Short press the  button to enter “**AUX IN**” mode (the speaker will voice “Aux in” mode). The speaker will play the music from the audio source.

Please note: Low battery will affect the music sound quality, please charge the speaker by adaptor (5V 1A) soon.

## PC USB Mode

Please use the USB cable included to connect the speaker to the computer, a



short press of the button to enter the PC USB Mode, which will operate as a computer speaker. The first time using this function, computer will automatically identify the speaker and install the driver.

(Please note: At this mode, it just has **MUTE** function no Pause.)

## Charging

The speaker with the built-in lithium battery, you can use the USB cable included to connect the speaker to the computer or a branded good quality 5V/1000mA adaptor to charge the battery. When charging, the LED indicator is orange, and after finished the charging, the LED indicator will turn blue.

Please note: (1) If low capacity, the indicator light will flash quickly, please charge immediately. (2) We recommend to charge the speaker by branded adaptor (5V 1A).

## Troubleshooting

### 1. What should I do if the speaker can not pair with the Bluetooth device and play music accordingly?

Please check the specification/ the manual of the Bluetooth device (your mobile or computer), and check if the device can support the A2DP stereo audio transmission. If yes, please turn on the A2DP stereo mode.

### 2. What should I do if the PC USB function could not work?

(1) Connect the speaker to the computer via the USB cable included, and enter the PC USB mode. And then play the video/ audio from the computer.

(2) If it could not work, it may be the problem that the sound card of the speaker is incompatible with the computer. Please try to click the device manager--- click the Voice video and games controller---right click the USB Audio device---click the uninstall. Then please switch the speaker to PC USB mode again. The computer will automatically update the USB sound card drive to achieve the compatibility

**Please note:** The USB sound card function only apply to Windows XP/ Windows vista/ Windows 7/Windows 8.