

ednet.




COLOR SPLASH

Quick Installation Guide


Quick Guide

Turn the volume to the minimum before connection.
Read the quick guide carefully before connection.

- (1) Connect the left speaker to the right with its connect cable.
- (2) Connect the left speaker and the computer with USB power cable.
- (3) Connect the left speaker and the portable player with 3.5mm mini plug cable.
- (4) Turn on the media player and adjust the volume to enjoy the light and water dance show.




Figures



Inbetriebnahme

Stellen Sie die Lautstärke auf die kleinste Stufe, und lesen Sie diese Anleitung sorgfältig, bevor Sie es verbinden.

- (1) Verbinden Sie den rechten Lautsprecher mit dem Linken mithilfe dem mitgeliefertem Verbindungskabel.
- (2) Verbinden Sie den linken Lautsprecher mit dem Computer und dem dazugehörigen USB-Kabel
- (3) Verbinden Sie den linken Lautsprecher mit einem tragbaren Gerät oder Notebook und dem 3.5mm Anschlusskabel.
- (4) Schalten Sie den Media Player ein und drehen Sie die Lautstärke auf, um die Licht- und Wassertanz Show zu genießen.



Datenblatt



ednet.



COLOR SPLASH

Kurzanleitung zur Installation