

ednet.




5A >A D E B >3E: Quick Installation Guide


Quick Guide

Turn the volume to the minimum before connection.
Read the quick guide carefully before connection.

- (1) Connect the left speaker to the right with its connect cable.
- (2) Connect the left speaker and the computer with USB power cable.
- (3) Connect the left speaker and the portable player with 3.5mm mini plug cable.
- (4) Turn on the media player and adjust the volume to enjoy the light and water dance show.



Figures



Package Contents

- (1) Speakers
- (2) 3.5mm mini plug cable
- (3) USB power cable

Description

- (A) Speaker (33mm)
- (B) Speakers' connect cable
- (C) Audio input jack
- (D) Mini USB port
- (E) 3.5mm audio output jack

www.assmann.com
ASSMANN Electronic GmbH
Auf dem Schüffel 3
D-58513 Lüdenscheid