



Wireless Charging Pad, magnetic



Quick Installation Guide
DA-10080

1. INTRODUCTION

The magnetic charging pad from DIGITUS® automatically latches on to the optimal charging position of the iPhone® to guarantee efficient charging. The induction charger features an integrated 1.0m long USB-C charging cable and works with all Apple Mag Safe®-compatible products.


2. FEATURES

1. Compatible with iPhone® 12/13.
2. Inductive charging technology for wireless charging of compatible smartphones.
3. The magnetic ring is optimized for the latest Apple iPhone® models and the charging function can be used with any smartphone that allows inductive charging.
4. Connection cable with USB-C plug.
5. Compact and robust aluminum/ABS housing with elegant look.
6. A power adapter is not included in the scope of delivery.

3. PACKAGE CONTENT


- 1x Wireless charging pad, magnetic
- 1x QIG (Quick Installation Guide)

NOTE: This charger is designed for Qi-compatible devices if your phone does not have built-in Qi wireless charging capabilities, please use a certified Qi wireless charging case or receiver. Refer to your phone's user manual for detailed features and functions



Phone cases that contain metal, magnets, or are thicker than 3mm will interfere with wireless charging.


Wireless Charger Output
15W/10W/7.5W/5W



This charger magnetically snaps to the back of an iPhone 12/13 or to its MagSafe case or sleeve (sold separately) and aligns iPhone properly, allowing you to hold and use iPhone while it's charging.



You can also use MagSafe Charger with other phone models that support wireless charging.



Plug the USB-C connector to a 20W PD or greater USB-C power adapter or compatible third-party USB-C adapter (9V/2.22A or 9V/1.67A and higher).

NOTE:

You can also connect to a USB-C port on a Mac or PC. The charger will also function with power adapters that provide a minimum 12W (5V/2.4A) of power, but this will result in slower charging.

iPhone 12/13 models





Place the charger on the back of the iPhone or its Mag Safe case or sleeve. When the iPhone starts charging, the green charging symbol appears.

NOTE:

If an iPhone Leather Wallet is attached, remove it before placing the charger on the back of the case.

Other phones

Place the phone face up on the center of the charger. When the phone is aligned properly with the charger, the Battery Charging icon appears in the status bar.

	Standby
	Charging
	Foreign Object Detected
	It's normal for a wireless charger and your device to become warm while charging.

Frequency band(s): 110-205khz	Maximum radio-frequency power transmitted -21.28 dBuA/m
----------------------------------	--

Read all safety instructions and warnings prior to using this product. Improper use and failure to follow safety guidelines could result in hazards, injury and/or property damage that is not the manufacturer's responsibility. The user is responsible for maintaining this product with care for maximum use.

1. Do not place metal objects, magnets, magnetic stripe cards, and hard drive based devices near the wireless charger. It may cause data corruption.
2. Do not attempt to modify, disassemble, or repair this product.
3. Do not expose to water, moisture, or extreme temperatures (below 40°F or above 90°F).
4. Under any circumstances, if you find this product rapidly increasing in temperature, emitting odor, or demonstrating an abnormal phenomenon, discontinue use immediately.

Hereby Assmann Electronic GmbH declares that the Declaration of Conformity is part of the shipping content. If the Declaration of Conformity is missing, you can request it by post under the below mentioned manufacturer address.

www.assmann.com

ASSMANN Electronic GmbH

Auf dem Schüffel 3

58513 Lüdenscheid

Germany

