

ednet.



User Manual

HEAD BANG

83131/83132/83133



Instructions:

- ① Power key/ telephone answering key
- ② Touch to increase the volume/ to pick previous song
- ③ Touch to reduce the volume/ to pick next song
- ④ Mic hole
- ⑤ USB charging port
- ⑥ AUX IN port

Features:

1. Bluetooth Version: 2.1+ EDR
2. Support Bluetooth phone calls, Bluetooth Music and re-dial last number
3. Finger Touch control design
4. Support PC voice communication(With special Mic Cable)
5. Support Computer, MP3, CD ...AUX in
6. Built-in lithium battery, with Micro USB charging port
7. Smart Electricity-saving (after 3 minutes no connection or 55 seconds no paring, it will turn off automatically to save the electricity.)

Specifications:


1. Wireless transmission distance: CLASS II
2. Battery capacity: 300MAH
3. Frequency range: 20-20KHZ
4. Sensitivity: 95DB




5. Speaker impedance: 32 ohm
6. Speaker Size: 32MM
7. Charging time: 2H
8. Voice Communication working time: 8-10H
9. Bluetooth Music Playing time: 8-10H
(Based on two-thirds of the maximum volume)


Operations:


1. Bluetooth Functions

Bluetooth pairing:


1. For first time pairing, press and hold  key for seconds to pairing mode, the light will indicate in BLUE and RED light flash in turn. When the pairing is successful, your device will show the connected Bluetooth icon (pairing name) "ED_Head Bang."


2. After successful pairing, press  key to play music sourcing from your device. Press again to pause. When there is phone call coming, press  key to answer the call directly, Press and hold  key for 3 seconds to change to mobile phone private answering. Press and hold on 3 seconds again back to Bluetooth answering.



3. Double click  key to call the Number which you made last phone call.

Bluetooth Music:






1. Click  key for once to play the music sourcing from your mobiles. Click again to pause.
2. Finger touch area is divided into two parts by ".". Quick click the volume to increase or reduce area to realize songs pick the next or previous.
3. Press and hold the volume control area, you can easily to increase or reduce the


volume continuously. When it reaches the maximum or minimum, the device will indicate with a tick voice.

Click non-continuously to increase or reduce the volume by steps.

Bluetooth phone calls:

1. When there is a phone call incoming, press  key to answer the call directly, press and hold on  key for 3 seconds to change to your mobile phone private answering, press and hold on once again to back to Bluetooth answering.
2. Double-click  key to call the Number which you made last phone call.

LINE IN function:




When you want to listen to the music sourcing from other audio devices, connect the Headphone with them, with the AUX in Cable inside the AUX in port as the picture shows.

On this model, the Bluetooth will turn off automatically, turn it on is not allowed.


Charging function:

1. Connect the Charging cable with a adapter or (Computer's USB port), while the other end insert into the USB charging port as pictures shows. This device will indicate in RED light keeping bright on the right when charging. When it is full, the RED light will turn off automatically.




Accessories:

AUX IN cable (length: 1.2M)
Charging Cable (length: 0.65M)



Measurement:



www.assmann.com
ASSMANN Electronic GmbH
Auf dem Schüffel 3
58513 Lüdenscheid
Germany