

**IDE - USB** 

2,5" HDD ENCLOSURE

(DA-70550)

**User's Manual** 

# 1. Characteristics

- 1) Compliant with both USB 2.0 and USB 1.1 standard specifications
- 2) High-speed data transfer rate up to 480 Mbytes
- 3) Complies with ATA/ATP-6 specification revision 1.0
- 4) 64/512 bytes data payload for full/high speed bulk endpoint
- 5) Supports 8-bit/16-bit standard PIO mode interface
- 6) Supports 16-bit multi-word DMA mode and Ultra DMA mode interface (Ultra 33/66/100)
- 7) Supports power down mode and USB suspend indicator
- 8) Supports wake-up ability

# 2. System Requirements

- 1) USB Interface: one free USB port.
- 2) OS: Windows 98SE/ME/2000/XP/Vista and MAC 9.X/10.X

# 3. Driver Installation

# Windows 98


1) Insert the driver CD-ROM into the CD-ROM drive , Plug the device to your computer, the system will detect it and start "Add New Hardware Wizard".



2) When you see the following screen, please click "Next".



3) When you see the following picture, please check "Search for the best driver for your device (Recommended)" and press "**Next**".



4) When you see the following screen, please press"Next"



5) When you see the following screen, please press"Finish"




# Windows ME/2000/XP/Vista and MAC 9.X/10.X

No need driver installation in those OS platform.

# 4. Verification

Please track the path "My computer→System Properties→Device Manager" and expand the item "Hard disk controllers", you should meet one item titled "JMicron SATA -USB Combo Device" and "USB Mass Storage Device".



# 5. If you use a all new HDD

- 1) Please use "Fdisk" to set the capacity of your HDD, but this will destroy all the data in the HDD.
- Format your HDD by standard procedures, if you can't find your new HDD, please following the steps in FAQ-1
- 3) NOTE: "Fdisk" or "Format" will destroy all the data and program in the HDD you select. Please make sure there is not any datain it, or all the data have a backup copy.

# 6. FAQ

Q1: I could see the icon at the right down comer on the screen, but I still couldn't find my external HDD.

A1:

- a. Please make sure your HDD has been installed correctly.
- b. Please make sure your HDD has been set in "Master" position.
- c. Please make sure you have installed correct driver for this enclosure.
- d. Please make sure your HDD has been formatted. If no, please format your hard drive first.
- e. If you are sure you have installed correctly all the hardware and software, please follow the steps as below to catch your HDD.
- f. Enter "Control Panel" and enter "System" icon
- g. Double click it to find a "System Manager
- h. Find a "Disk" category. There should be 3 drivers, double click "Generic STORAGE DEVICE USB Device."
- i. Find the "Setting" button and choose the option "Removable Drive".
- j. Your computer will automatically assign a new letter to this protable HDD after restarting your computer.
- Q2. Why I couldn't find my enclosure at all?
- A2: This situation somethings happens to some notebook models. That's because a few notebook maufactures remove the power current from USB port to reduce the heat in the notebook. Or some old models couldn't supply sufficient power for USB. This problem mostly couldn't solve the problem, please buy a AC power adaptor to offer sufficient power for enclosure.

#### 7. CAUTION!!

- a. When using USB 2.0-interface model, external p ower is needed when HDD consumes power over 550mA.
- b. If you are not sure what OS you are using, please contact your PC dealer.
- c. Please don't put this external enclosure in a humid or high-temperature environment.
- d. If your first installation is failed, please firstly remove the wrong device throung the path as below: Path=Control Panel > System > System Manager > PCI to USB Open Host Controller > Please remove the items with "?" or "!"mark.

# 8. ADVICE

It's recommended that you use this USB IDE External Enclosure in bus-power mode. If it can't work properly, please use it in self-power mode.



1. Carefully remove cover from HD enclosure



4. Assemble PCB shielding above PCBA



2. Insert PATA hard drive



5. Replace cover onto HD enclosure



 Securely tighten screws from the bottom of HD enclosure to fix hard disk (4pcs short screws)



6. Use screws (2pcs longer, 2pcs shorter) from the bottom of HD enclosure to tighten it



7. Plug mini USB into the HD enclosure



8. If additional power is needed, plug DC power into HD enclosure



9. Plug USB and DC cable into PC or laptop

7