



User Manual (DA-70155)

Index: A. USB-Serial Cable B. USB-Serial Converter C. How driver works with Modem on Linux RedHat 7.3

# A. USB-Serial Cable

- 1. Product Features
- 2. System Requirements
- 3. Driver Installation (WIN2000)
- 4. Changes COM Port
- 5. Setting Up the RS232 Serial Device

#### **1. Product Features**

- USB Specification Rev. 1.1 compliant
- Support the RS232 Serial interface
- Over 1Mbps data transfer rate
- Support remote wake-up and power management

### 2. System Requirements

- IBM PC 486DX4-100 MHz CPU or higher or compatible system
- Available USB port
- CD-ROM drive
- Windows 2000

### 3. Driver Installation (WIN2000)

Follow the steps below to install Window 2000 driver of USB-Serial cable:


- 1. Power on your computer and make sure that the USB port is enabled and working properly.
- 2. During installation, please don't link USB-Serial cable with your computer.
- 3. Double click 'setup.exe', then it will start install



- 4. After installation, click 'OK '
- 5. Plug in the USB-Serial cable into the USB port and run the **Found New Hardware Wizard** to assist you in setting up the new device. Click **next** to continue.

Found New Hardware Wizard	
	Welcome to the Found New Hardware Wizard This wizard helps you install a device driver for a hardware device.
	< <u>B</u> ack <u>Next&gt;</u> Cancel

6. Click Next to continue. Select the " Search for a suitable driver for my device (recommend) "




7. Windows will detect the driver and Click Next to continue installation.

Found New Hardware Wizard
Driver Files Search Results The wizard has finished searching for driver files for your hardware device.
The wizard found a driver for the following device:
Windows found a driver for this device. To install the driver Windows found, click Next.
a:\serport.inf
< <u>B</u> ack <u>Next&gt;</u> Cancel

8. Click Finish to continue and let Windows copy the needed files to your hard disk.




9. You can to check the Device Manager and see the Prolific USB to Serial Com Port)



#### 4. Changes COM Port

Under Windows 98SE, you can change the COM Port via **setcom.exe** <sup>[5etCOM.exe]</sup> software 7. Under Windows Me 、 Windows 2000 、 Windows XP, please kindly following the steps as below.

(1) Please click on the **Device Manager**  $\Delta$  **Devices by connection**  $\Delta$  **ports (COM & LPT)**. (image 1)



(image 1)

(2) Doubly click on "**Prolific USB-to- serial Com port(COM3)**" .And it could go to ' **properties**'. (image 2)

Prolific USB-to-Serial Comm Port (COM3) Properties
General Port Settings Driver
Bits per second: 9600
Data bits: 8
Parity: None
Stop bits: 1
Elow control: None
<u>A</u> dvanced <u>R</u> estore Defaults
OK Cancel

(image 2)

(3) Please choose **"Port Settings** ", and then click on **"Advanced**". Please kindly choose the needed com, and click on **"ok"**. (image 3)

Advanced Settings for COM3	<u>? x</u>
✓ Use FIFO buffers (requires 16550 compatible UART) Select lower settings to correct connection problems. Select higher settings for faster performance.	OK Cancel
Beceive Buffer: Low (1)	<u>D</u> efaults
Iransmit Buffer: Low (1) COM3 COM4 COM5 High (16) (16)	
COM6 COM6 COM Port Number: COM3	

(image 3)

Notice:

If the Modem could not link with the new port, and run smoothly when changed the port, please kindly unload Modem, and re-install it.

When changing the port, the peripheral equipment could not shift to the new port, and run smoothly. Under this situation, please kindly unload the equipment and install again.

### 5. Setting Up the RS232 Serial Device

Follow the steps below to connect your RS232 Serial Device (ie: Modem) to the USB port of your PC:

- 1. Turn off your Modem. Plug the DB 9 connector of the USB-Serial cable into your Modem. Turn on the Modem afterwards.
- 2. Turn on your computer and plug in the USB connector of the USB-Serial cable into the USB port.
- 3. If you have already installed a Modem device before, click Start, Settings, Modems. Open Modems Properties, select the Modem and click Properties. In General tab, please change the **Port** value to **USB to Serial Port (COM3)**.
- 4. After finishing these processes, you can use USB to Serial Bridge Cable to connect RS232 Serial 56K FAX Modem and execute the Dial-up function to connect Internet, and send the FAX with the FAX software(ie: Microsoft FAX) properly.

Standard 56000 bps V90 Modem Properties	? ×
General Connection	
Standard 56000 bps V90 Modem	
Port: USB to Serial Port (COM3) Communications Port (COM1) Speak USB to Serial Port (COM3) Virtual Infrared COM Port Off On	
<u>Maximum speed</u>	
115200	
Only connect at this speed	
ОК Са	ancel

# **B. USB-Serial Converter MAC DRIVER**

- 1. Overview
- 2. Product Features
- 3. System Requirements
- 4. Driver Installation

## 1. Overview

Congratulations on your purchase of the wiretek USB-Serial Converter. This device provides a simple and easy way to connect Universal Serial Bus (USB) and Serial port interface.

With the advantage of USB port, users have the capability to utilize the peripheral with serial port interface in an easy to use environment such as plug and play & hot swap function. This Converter is designed for ideal connections to Cellular Phone, Digital Camera, Modems or ISDN terminal adapter with over 1Mbps data transfer rate.

The USB-Serial Converter and software drivers are capable of providing a no-firmwarechange feature that enable USB interface to be transparent to serial port peripherals with minimum modifications.

### 2. Product Features

- USB Specification Rev. 1.1 compliant
- Support the RS232 Serial interface
- Over 1Mbps data transfer rate
- Support remote wake-up and power management


### 3. System Requirements

- Power G3 OR G4 CPU or higher or compatible system
- Available USB port
- CD-ROM drive
- Mac OS 8.6 or Higher

## 4. Driver Installation

Follow the steps below to install driver of USB-Serial Converter:

- 1. Power on your computer and make sure that the USB port is enabled and working properly.
- 2. Insert the USB-Serial Converter software driver into the CD-ROM drive.
- 3. Plug in the USB-Serial adapter into the USB port and run the pl2303.SIT from the CD-ROM, it will auto run the program and appear a **PL-2303 system extensions**.



- 5. Copy the PL-2303 system extensions to the system Folder-Extensions.
- 6.

4.

173 itomo, 1.68 CB available				
Name	Date Modified	Size	Kird	
(a) Then 3 Renderer (41)	Thu, Act 28, 1999, 3:00 AM	208 K	ihrary	
Den3_Utility	Thu, 0ct 20, 1999, 3.00 AM	21C K	ibrary	
🕼 OpenTot Madem	The, Alig 31, 1999, 3:00 AM	92 K	ihrery	
🚯 DpenTot Remote Access	Tue, aug 31, 1999, 3.00 AM	1 MD	ibrery	
🚯 OpenTot Serial Antitrator	Tue, Alig 31, 1999, 3:00 AM	۶κ	ihrary	
🙀 DpenTotON*1PL b	Sat, Mar 20, 1999, 4 CO AM	46C K	ibrary	
P_2301Driver	Sat, Feb 19, 2000, 2:15 PM	16 K	system extersion	
P 2303	Wec, Aug 9, 2000, 2.40 PM	2C K	system extension	
P_23074IM	Sun, May 14, 2000, 9:47 PM	εĸ	system extersion	
P_2307Driver	Sun, Hay 14, 2000, 5:46 Pr1	2C K	system extension	
Printer Descriptions	Thu, Jan 6, 2000, 12 55 4M	10.000	folcer	
Printer Share	Tulay, 9:03 At1	8C K	system extension	
PrintingLip	Sat, Aug 14, 1999, 3:00 AM	88C K	ibrery	
Print Monistor	Wet, Fall 24 1995, 1:31 AM	6 <b>⊂</b> K	application program	
[슈] QD 3DC ustom Elements	Tue, Sep 14, 1999, 3:00 AM	2C K	ibrary	
Q QuickDraw" 3D	Tue, 3cp 14, 1999, 3:00 4M	1.2   16	system extension	
QuickDraw™ 3D F	Tue, Sep 14, 1999, 3:00 AM	212 K	ibrery	1

7. To make sure that your computer can use the device correctly, you have to check the **Apple System Profiler-Device and Volumes**. It will show the USB Device.

Syntam Point N     Douglas are schure V     Letter 2010 V     Letter 2010 V       Fr     Nextdo-repret to (Profile Diction exp Pro)     Douglas (Provide Diction exp Pro)       Sh     Provide Diction exp Pro)     Douglas (Provide Diction exp Pro)       Sh     Provide Diction exp Pro)     Douglas (Provide Diction exp Pro)       Sh     Provide Diction exp Pro)     Douglas (Provide Diction exp Pro)       Sh     Provide Diction exp Pro)     Douglas (Provide Diction exp Pro)       Sh     Provide Diction exp Pro)     Douglas (Provide Diction exp Pro)       Sh     Provide Diction exp Pro)     Douglas (Provide Diction exp Pro)       Sh     Provide Diction exp Pro)     Douglas (Provide Diction exp Pro)       Sh     Provide Diction exp Pro)     Diction exp Pro)       Sh     Provide Diction exp Pro)     Diction exp Pro)       Sh     Provide Diction exp Pro)     Pro)       Sh     Provide Diction exp Pro)     Diction exp Pro)       Sh     Provide Diction exp Pro)     Diction exp Pro)       Sh     Pro)     Provide Diction exp Pro)     Diction exp Pro)       Sh     Pro)     Pro)     Pro)     Pro)	Thursday I have	- N / 10		Apple System I'r			
by Modor-Speet of (Profile Decline og Pro) Nodo: Profile Techne og Pro) Nodo: Profile Techne og Pro) Dr ver varbor: (Del Dr ver varbor: (Del Del Del Del Del Del Del Del Del Del Del Del Del Del Del Del Del Del Del Del Del Del Del Del Del Del Del Del Del Del Del Del	in c			V some sers V ac	clications V system Fo	idens 7	
Node: Point Close ey, PC.   Dr. ver vesty:: 100 for frame ey, PC.   Dr. ver vesty:: 100 for frame ey, PC.   Dr. ver under: F. 23.55   Power (n.k. 50.03 fb) Ber al number:   Power (n.k. 50.04 fb) Ber al number:   Wrath # 0 Ber al number:   Power (n.k. 50.04 fb) Ber al number:   Wrath # 0 Ber al number:   Vibition: Ber al number:   Vibition: Ber al number:   Vibition: Ber al number:   Vibition: Ber al number:   Description: Ber al number:   Vibition: Ber al number:   Description: Ber al number:   Descrit Ber al number: <t< th=""><th></th><th></th><th></th><th></th><th></th><th></th><th></th></t<>							
Privative (Privative Treatment of privative   Privative Privative	an						
Dr var verski : Loai Dr var verski : 500 (5: 45) Pe este enariter : 10 Ser al samzer : Posifie Techno egy re. strat (A <sup>+</sup> b : b   D=0 end or kr b   D=0 u-44.D1 5 r/se b   D=0 u-44.D1 5 r/se d Viki b   Paill=lin i ig leg isent b Display			Prolific Technology, Inc. (Real file Technology, Inc.)				
Power (n.k. 520 (8' r4) Pesse anatver 10 Ber al runsor : Prolifio Technology re. Wrat A <sup>24</sup> 2       <u>b</u> 0 and or ive							
Pe sa e normer 1.0 Ber al unov: Politio Techno oy re. mra14 <sup>24</sup> 4 ↓   D=0 ord or tre wra14 <sup>24</sup> 4 ↓   D=0 u-44.19 ±rrae ↓   D=0 u-44.							
Ber al hancor: Polific Technology re.   mrail 4" 4.2 b 00 ord ordre   b 00 ord ordre b 00 ordre   b 00 ordre b 00 ordre   ar 112 a. b 00 ordre   b 00 ordre b 00 ordre							
mrs1 A <sup>ar A</sup> 2 b 10 - 0 erd onke wrs1 A <sup>ar A</sup> 2 b 10 - 0 LubeLP 3 r/w d Viki b Faill-Innik legiserd > ticplay							
b   b = 0     and crive     b     b     and crive     and crive     b     and crive     an		Ser al humber:	Prolific Technology ro.				
arrild 4 - b 10-0 - U-MLP131700 - b 10 Pr.A. 1 Viki b Prull-Inc ky legicord > b tarpiny	erral ATA 2	h (m			o bec arecera	<i></i>	12
blib-0_U-MLP1 stroke stroke blib-in oka lego sord bitspiny			and critice		Tabintosh II	1	
blib-0_U-MLP1 stroke stroke blib-in oka lego sord bitspiny							1
b (Poull=lin is by Foysierd) > Display		D - 0	LU-MLM drive		6 6 MA-		
b (Poull=lin is by Foysierd) > Display		2,282 104 9					
	3	Viller	Norma and a second		1		(C)
			- Menutani Makatan		bisbish		
to t							

# C. How driver works with Modem on Linux RedHat 7.3

I am believed that you already have PL-2303X/H Linux driver source, and you also know how to compile it in Linux, so I only explain how to link device with our driver.

In Makefile file, we had set a command to insert driver into Kernel, so you can type "make inst" to insert driver, after that, please type "dmesg" command then click enter, you will see messages appeared on screen, please force on the least line of message," usbserial.c"

The Prolific USB Serial Adapter converter now attached to ttyUSB0 (orusb/tts/0 for devfs).

It means the virtue COM port is in ttyUSBO, so if you want to use this port, you need to use "In" command to hard link with device, for example: we are use PL-2303X/H to connect with modem (or ttySO), so we need to type "In -b /dev/ttyUSBO /dev/ttySO" then click enter, if nothing happen and the screen appear "[root@localhost / xxxxx]#", then link operation is successfully, next, you need to execute Start→Programs→System→Internet configuration wizard to setup modem and it port,

- 1. On "Select Device Type" dialog box, please chose "Modem Connection", please ignore the "can't not find modem" message and then click next, on this dialog box, and on "Modem Device" item to selects "/dev/ttyS0", click next.
- 2. On "Selection Provider" dialog box, please fill in the dial number, account and password.
- 3. Click "Finish" button to the next step.
- 4. On the next dialog box, all setting information are in this box, please make sure all the setting as you want.
- 5. Click "Apply" and "Close" to leave setup wizard.
- 6. To execute Start→Applets→Network→Modem Lights, a small icon will appear on the left-bottom of panel bar, when you want you connect internet, you can click the green light to do dial-up, after that, you can launch internet application program to browser internet.
- 7. To click Red light to disconnect dial-up.