



RS 232 SERIAL EXPRESS CARD



User Manual
DS-31204-1

Features and Benefits

- Fully compliant with ExpressCard Specification 1.0
- ExpressCard/34 Form Factor Module
- Provides one DB9 RS232 port
- Supports serial transmission rate up to 230400bps
- No IRQ resource required
- Bus Powered – no separate power supply or battery required
- Easy Plug and Play Installation
- Works with various types of RS232 serial devices including modems, PDAs, label printers, bar code scanners, digital cameras, and more
- Supports Windows[®] 2000, XP, Vista, Windows 7

Package Contents

- 1 x ExpressCard Serial 1-Port
- 1 x Driver CD
- 1 x User Manual

System Requirements

- Windows[®] 2000/XP/Server 2003/Vista/Windows 7
- ExpressCard-enabled system with an available ExpressCard slot

Hardware Installation

General instructions for installing the card are provided below. Since the design of system may vary, refer to your system's reference manual for further information, if needed.

Insert the ExpressCard Serial 1-Port into the ExpressCard slot of your system. Make sure it is inserted all the way in for a solid connection.

Driver Installation

For Windows® 2000/XP/Server 2003

1. Don't insert the Serial 1-Port ExpressCard into the ExpressCard slot.
2. Please insert the CD driver bound with Serial 1-Port ExpressCard into your CD-ROM Drive.
3. At the Windows desktop click **Start**, then **Run**.
4. **CD ROM: \Driver\Setup.exe**, then click **OK**.
5. Follow the on-screen instructions to complete the installation.
6. Insert the Serial 1-Port ExpressCard into the ExpressCard slot.
7. Open "Device Manager" under System Properties and check if there is the device you install under "**Prolific USB-to-Serial Comm Port ...**".
8. Now the Serial 1-Port ExpressCard is ready to use.

For Windows[®] Vista / Windows 7

1. Don't insert the Serial 1-Port ExpressCard into the ExpressCard slot.
2. Please insert the CD driver bound with Serial 1-Port ExpressCard into your CD-ROM Drive.
3. At the Windows desktop click **Start**, then **Run**.
4. **CD ROM: \Driver\Setup.exe**, then click **OK**.
5. Follow the on-screen instructions to complete the installation.
6. Insert the Serial 1-Port ExpressCard into the ExpressCard slot.
7. Open "**Device Manager**" under System Properties and check if there is the device you install under "**Prolific USB-to-Serial Comm Port ...**".
8. Now the Serial 1-Port ExpressCard is ready to use.

Changing COM Port Number

Some serial devices need a special COM port in order to work. If your serial device works properly, do not change this setting.

1. From the **Device Manager** window double click **Ports (COM & LPT)**, then double click the **Prolific USB-to-Serial Comm Port** if you want to change.
2. Click **Port Settings** tab and click **Advanced...** button.
3. Click the down arrow that is next to the **COM Port Number** box, select a COM port that is not in use, then click **OK**. Click **OK**, then close **Device Manager** to save the changes.

Hereby ASSMANN Electronic GmbH, declares that this device is in compliance with the requirements of Directive 2014/30/EU and the Directive 2011/65/EU for RoHS compliance. The complete declaration of conformity can be requested by post under the below mentioned manufacturer address.

Warning:

This device is a class B product. This equipment may cause some radio interference in living environment. In this case, the user can be requested to undertake appropriate measures to prevent interference.

www.assmann.com

Assmann Electronic GmbH

Auf dem Schüffel 3

58513 Lüdenscheid

Germany

