


SATA II PCI EXPRESS CARD



User Manual

Features and Benefits

- Compliant with PCI Express Base Specification 1.0a
- Compliant with Serial ATA 1.0a specification with support for full complement of SATA II optional features
- PCI Express 1-lane (x1) SATA II adapter works with PCI Express slots with different lane width
- Installs in any available PCI Express slot and support data transfer rates up to 3.0Gbps (300MBps)
- Supports Native Command Queuing (NCQ), Non-zero offsets NCQ, and Out-of-order date delivery NCQ
- Independent command fetch, scatter / gather, and command execution
- Hot-swapping feature allows you to attach/detach SATA device without first powering your computer off
- Supports Windows 7, Vista, XP, 2000


Package Contents

- 1x PCIe SATA II 300 Card
- 1x SATA Cable
- 1x SATA Power Cable
- 1x Driver CD
- 1x User Manual

System Requirements

- Windows 7, Vista, XP, 2000
- PCI Express-enabled system with an available PCI Express slot

Hardware Description



Jumper Settings		
JP	Description	Active Port
J1-J4	1-2 close	Enable SATA Connector 1
	2-3 close	Enable SATA Connector 2

Note: There are two SATA ports in PCIe SATA II 300 Card. We

name these ports A and B. Port A is external SATA port and B is internal SATA port. Only one of them will work but not both at the same time. Please set which port to work by jumper setting. By default, Port B is working.

Hardware Installation

- 1. Turn off the power to your computer.
- 2. Unplug the power cord and remove your computer's cover.
- 3. Remove the slot bracket from an available PCIe slot.
- 4. To install the card, carefully align the card's bus connector with the selected PCIe slot on the motherboard. Push the board down firmly.
- 5. Attach your internal or external devices to the PCIe SATA II 300 Card.
- 6. Replace the slot bracket's holding screw to secure the card.
- 7. Replace the computer cover and reconnect the power cord.

Driver Installation

For Windows® XP/Server 2003

1. At the Found New Hardware Wizard:

XP(w/SP1 or earlier) /Server 2003: continue to step#2 XP(w/SP2 or later)/Server 2003(w/SP2 or later): Select **No**, **not this time**, then click **Next**.

- 2. Please insert the driver CD into your CD-ROM Drive, select **Install the software automatically(Recommended)**, and click **Next**.
- 3. Accept the default entry, then click Next.
- 4. Click Finish.
- 5. Repeat steps 1-4.
- 6. Click **Yes** to restart to complete the installation.

For Windows® 2000

- 1. At the Found New Hardware Wizard, click Next.
- 2. Select Search for a suitable driver for my device(recommended) then click Next.
- Insert the driver CD into your CD-ROM Drive, check CD-ROM drives, uncheck the other boxes, click Next, then click Next again.

4. Click Next, then Finish.

- 5. Repeat steps 1-4.
- 6. Click **Yes** to restart to complete the installation.

To Verify Windows® 2000/XP/Server 20003 Installation

Click on the "Device Manager" tab in System Properties, which you access from the Windows Control Panel. You should see an "Silicon Image Sil 3531 SATA Controller" installed under "SCSI and RAID controllers" item.

START > Control Panel > System > Device Manager

CSI and RAID controllers

Hot-Plugging A Hard Disk Drive

To remove a drive from a powered up system, do the following:

- 1. Right click **My Computer** and click **Manage**.
- 2. Select Device Manger.
- 3. Click **Disk Drives**, right click the target disk and select **Disable/Enable**.
- 4. You can now remove the target disk.