



## 6600mAh Power Bank



**User Manual  
31887**

## Introduction

Charge your iPhone®, iPad® or Smartphone On-The-Go with this 6600mAh Power Bank Charger.

It is suitable for iPhone®/iPad®/iPod®, smartphones, tablets, digital cameras, GPS devices, Bluetooth headsets or any other portable USB device.


The 2.1A output allows fast charging of your phone or tablet and the built-in LED torch can always come in handy Carry this power bank with you everywhere you go and never miss that important phone call, text or email.

## Suitable for

- iPhone®/iPad®/iPod®
- All smartphones including Samsung, HTC, Motorola, Nokia, LG, Sony, BlackBerry & more
- Tablets from Samsung, Kindle, Sony & more
- GPS devices
- Portable Bluetooth devices such as headset, hands free car kit, speaker etc.
- Portable handheld video games eBook players

## Features

- Large 6600mAh is enough capacity to fully charge an iPhone® or an average smartphone up to 3 times
- 2.1A output for fast charging
- Four LED indicators to show remaining capacity
- Handy built-in LED torch
- Built-in over charging and short circuit protection



## **Item Specification**

- Capacity 6600mAh Li-ion Battery
- Input Connector 1 x Micro USB female
- Input DC 5V 2A
- Output Connector 1 x USB Type A female
- Output DC 5V 2.1A (Max)
- Charging Time 5 to 6 hours
- Size (L x W x H) 98 x 61 x 23mm
- Weight 180g

## **LED Torch Operation**

Press the power button for 3 seconds and the torch will turn on.  
Press again for 3 seconds to turn torch off.

## **To Check Remaining Capacity**

Press the power button and the capacity LED's will come on.  
After 10 seconds the LED's will turn off automatically.

- 4 x LEDs on: 75%~100% remaining capacity
- 3 x LEDs on: 50%~75% remaining capacity
- 2 x LEDs on: 25%~50% remaining capacity
- 1 x LED on: less than 25% remaining capacity

## **To Charge Power Bank**

- Using the included USB Type A to Micro USB Type B cable, connect the larger USB Type A connector to an AC wall adapter or USB port on a computer
- Connect the smaller Micro USB Type B connector to the Input connector on the power bank
- During charging the LED's will flash to show status
- When charging is complete all four LED's will be permanently on

## **To Charge Mobile Phone, Tablet or Other Device**

- Using your phone, tablet or other device's charging cable, connect the USB Type A connector to the Output connector on the power bank
- Connect the other end of the cable to your device
- Charging should commence automatically. If it doesn't, press the power button
- If your phone or device uses a standard Micro USB Type B connector then you can also use the included cable to charge your device
- When your phone or device is fully charged, the power bank will automatically turn itself off

## **Important Safety Instructions**

- To maximize battery life span, fully charge power bank before first use for 8 to 10 hours
- Store power bank in a cool and dry place.
- Do not store power bank in hot or humid environment
- Operating temp. should be between -10 to 45
- If power bank is not used for long periods of time, you should charge and discharge once per month
- When charging a device, the power bank may feel warm, this is a normal operating condition and should not be cause for concern
- In normal conditions, the battery performance will decline over several years
- Do not dispose of power bank in heat or fire
- Misuse, dropping or excessive force may cause product damage